



Private Water Testing Form

Water Diagnostics
Labs, LLC.
(414) 350-1100

8605 W. Freistadt Road
Mequon, WI 53097

Reason for Test

- Annual Test
- Taste or Odor
- Other _____
- Real Estate
- Previous Unsafe

Sample Location

- Pressure Tank Tap
- Bathroom Tap
- Outside Spigot
- Kitchen Tap
- Laundry Tap



Collection Date

Time

Owners Name

Street Address

City

State

Zip

Telephone #

()

County

Email Address for PDF Copy Instead of Mailing Report

Laboratory Use Only: EPA / State Approved Method Results

<input type="checkbox"/> Colony Count	Safe _____ Unsafe _____	<input type="checkbox"/> E. Coli Absent	Present _____
<input type="checkbox"/> Nitrates	_____	<input type="checkbox"/> Arsenic	_____
<input type="checkbox"/> Fluoride	_____	<input type="checkbox"/> pH	_____
<input type="checkbox"/> Iron	_____	<input type="checkbox"/> IRB	_____
<input type="checkbox"/> Lead	_____	<input type="checkbox"/> SRB	_____
<input type="checkbox"/> Copper	_____	<input type="checkbox"/> Mercury	_____

Date/Time Received:

Date Reported:

Laboratory Sample No:

Please Fill Out the **Red Text** and **Check the Box/Boxes Next to the Test** You Would Like the Laboratory to Analyze.

- Total Coliform Bacteria & E. Coli (Presence/Absence) - \$30.00
- Total Coliform Bacteria & E. Coli (Colony Count)-\$35.00 recommended
- Nitrate - \$30.00
- Iron - \$30.00
- Fluoride - \$30.00
- Lead - \$30.00
- Copper - \$30.00
- Nitrite - \$30.00
- Arsenic - \$35.00
- Mercury - \$75.00
- Iron Bacteria - \$45.00 takes at least 7-9 days to run
- Sulfate Bacteria - \$45.00 takes at least 7-10 days to run
- Total Hardness (Calcium / Magnesium)- \$100.00
- Chlorine - \$35.00
- Speciation Arsenic III & V- \$95.00
- Coliform Bacteria+ Nitrate+ Arsenic* Kit -\$85.00
- Other _____
- _____ Aluminum _____ Antimony _____ Barium _____ Beryllium _____ Cadmium _____ Chloride
- _____ Chromium _____ Manganese _____ Selenium _____ Sodium _____ Sulfate _____ Thallium
- _____ Uranium _____ Zinc
- * Please Add \$30.00 for Each Additional Test*
- Sampling Fee - \$75.00 (Within 10 mile radius)

Please make checks payable to Water Diagnostics, LLC. Payment is due upon receipt of sample/s to the laboratory.

PLEASE NOTE: TOTAL COLIFORM BACTERIA/E.COLI AND NITRATE TESTS SHOULD BE RECEIVED IN THE LAB WITHIN 24 HOURS OF SAMPLING & NEED TO BE KEPT COOL BETWEEN SAMPLING AND DROP OFF.

Water Diagnostics, LLC is a State Certified Laboratory
WI DATCP #105-461 USEPA Lab ID WI01119 WI DNR Lab Certification # 246103990

SAMPLING INSTRUCTIONS

Please verify the bottles have all the information needed. Label them with your name, date and time of collection, and faucet location.

REMEMBER TO FLUSH OUT THE LINE BY LETTING THE WATER RUN FOR AROUND TEN (10)MINUTES.

THE BEST PLACE TO TAKE A WATER SAMPLE IS FROM A SPOT CLOSEST TO THE WELL OR FROM WHERE THE WATER IS DRAWN FOR DRINKING. MAKE SURE THE FAUCET IS NOT CONNECTED TO A WATER SOFTENER, WATER HEATER OR IN-LINE FILTRATION SYSTEM.

If you take the sample from a faucet with an aerator (little screen) remove the aerator before you collect the sample.

TOTAL COLIFORM BACTERIA:

DO NOT RINSE OUT THE BOTTLE. The powder in the bottle is meant to be there and will not contaminate your sample. **WASH YOUR HANDS** prior to taking the sample. Then remove the sterile strip from the bottle. **REMOVE FAUCET SCREEN** or other hoses or aerators from the end of the faucet. If possible avoid using a faucet that swivels or has a pull-out spray hose. **DISINFECT THE FAUCET** by dipping the end in a cap full of bleach before running the water. **RUN THE COLD WATER FOR AT LEAST 10 MINUTES** to ensure that the water has not ben sitting in the pipes or tanks for a long time. **TURN THE WATER DOWN** so it does not splash. Remove the security seal, and then remove the sample bottle cap without touching the inside of the cap or bottle. Hold onto the cap while sampling. Fill the bottle to at least the fill line (100 mL mark). Do not fill it all the way up to the top, allow 1" head space. **SCREW THE CAP ON TIGHTLY. FILL OUT THE PAPERWORK.**

ARSENIC, NITRATE, IRON, FLUORIDE, PH, MERCURY, IRON BACTERIA, SULFATE BACTERIA, TOTAL HARDNESS, OR ANY OTHER TEST EXCEPT LEAD & COPPER:

Follow instructions as above, except you do not need to try to sterilize the faucet first.
Fill the bottle to the neck.

LEAD & COPPER

Flush the cold water line for approximately 10 minutes 6-8 HOURS BEFORE SAMPLING.
The system should remain UNDISTURBED for a period of at least 6 hours, but not more than 8 hours.
Collect the FIRST water as the tap is opened.
Fill the bottle to the neck.

Water Diagnostics
Labs, LLC.



8605 W. Freistadt Road
Mequon, WI 53092

(414) 350-1100

Please, drop the bottle/s off, ship or mail them priority if they need to be at the lab within a certain time frame.